

## Selection and ordering data

Description	7MB-2121	7MB-2123	7MB-2124	7MB-2111	7MB-2112	7MB-2111/2 Ex				Order No.
							2 years (quantity)	5 years (quantity)		
<b>Analyzer unit</b>										
O-ring for cover (window)	x	x	x	x	x	x	2	4	D)	<b>C79121-Z100-A24</b>
Cover (cell length 20 ... 180 mm)	x	x	x	x	x	x	2	2		<b>C79451-A3462-B151</b>
Cover (cell length 0.2 ... 6 mm)	x	x	x	x	x	x	2	2		<b>C79451-A3462-B152</b>
O-rings, set	x	x	x	x	x	x		1	D)	<b>C79451-A3462-D501</b>
<b>Sample gas path</b>										
O-ring (hose clip)				x	x	x	2	4	D)	<b>C71121-Z100-A159</b>
Pressure switch	x	x	x				1	2		<b>C79302-Z1210-A2</b>
Flow indicator	x	x	x				1	2		<b>C79402-Z560-T1</b>
Hose clip	x	x	x	x	x	x		1		<b>C79451-A3478-C9</b>
Heating cartridge (heated unit)				x	x	x		1		<b>W75083-A1004-F120</b>
<b>Electronics</b>										
Temperature fuse (heated unit)				x	x			1		<b>W75054-T1001-A150</b>
Fuse (device fuse)						x	1	2		<b>A5E00061505</b>
Temperature controller - electronics, 230 V AC				x	x	x		1		<b>A5E00118527</b>
Temperature controller - electronics, 115 V AC				x	x	x		1		<b>A5E00118530</b>
Fan, 24 V DC (heated unit)				x	x	x		1		<b>A5E00302916</b>
Front plate with keyboard	x	x	x				1	1		<b>C79165-A3042-B504</b>
Temperature sensor				x	x	x		1		<b>C79165-A3044-B176</b>
Adapter plate, LCD/keyboard	x	x	x	x	x		1	1		<b>C79451-A3474-B605</b>
Motherboard, with firmware: see spare parts list	x	x	x	x	x	x		1		
LC display	x	x	x	x	x		1	1		<b>W75025-B5001-B1</b>
Connector filter	x	x	x	x	x			1	F)	<b>W75041-E5602-K2</b>
Fuse, T 0.63 A/250 V	x		x	x	x	x	2	3		<b>W79054-L1010-T630</b>
Fuse, T 1 A/250 V	x	x	x	x	x	x	2	3		<b>W79054-L1011-T100</b>
Fuse, T 1.6 A/250 V		x	x				2	3		<b>W79054-L1011-T160</b>
Fuse, T 2.5 A/250 V				x	x	x	2	3	D)	<b>W79054-L1011-T250</b>

D) Subject to export regulations AL: 9I999, ECCN: N

F) Subject to export regulations AL: N, ECCN: EAR99H

If the ULTRAMAT 6 was supplied with a specially cleaned gas path for high oxygen context ("Clean for O<sub>2</sub> service"), please ensure that you specify this when ordering spare parts. This is the only way to guarantee that the gas path will continue to comply with the special requirements for this version.