


Overview

3RT2 contactors and coupling relays
Size S00 with mountable accessories

The SIRIUS generation of controls is a complete, modular system family, logically designed right down to the last detail, from the basic units to the accessories.



① Contactor size S00

- ② 1-pole auxiliary switch block, laterally mountable
- ③ 1-pole auxiliary switch block, for snapping onto the front, cable entry from above
- ④ 2-pole auxiliary switch block, for snapping onto the front, cable entry from below
- ⑤ 4-pole auxiliary switch block, for snapping onto the front
- ⑥ 3RA28 function modules
- ⑦ 3RA27 function modules for AS-Interface, direct starting
- ⑧ 3RA27 function modules for IO-Link, direct starting
- ⑨ Surge suppressor with/without LED

- ⑩ Three-phase feeder terminal
- ⑪ Star jumper, 3-pole, without terminal
- ⑫ Link for paralleling, 3-pole, with terminal
- ⑬ Wiring modules, on the top and bottom (reversing duty)
- ⑭ Solder pin adapter
- ⑮ Connection module (adapter and connector) for contactors with screw connection

● For contactors

● For contactors and coupling relays (interface)


For mountable overload relays see Chapter 5 "Protection Equipment --> Overload Relays".
For fuseless load feeders see Chapter 6 "Load Feeders and Motor Starters" --> "3RA2 Load Feeders".

3RT Power Contactors for Switching Motors

General data

3RT2 contactors

Size S0 with mountable accessories



NSB0_02057

- ① Contactor size S0
- ② 1-pole auxiliary switch block, laterally mountable
- ③ 1-pole auxiliary switch block, for snapping onto the front, cable entry from above
- ④ 4-pole auxiliary switch block, for snapping onto the front
- ⑤ 2-pole auxiliary switch block, for snapping onto the front, cable entry from below
- ⑥ Surge suppressor with/without LED
- ⑦ 3RA27 function modules for AS-Interface, direct starting
- ⑧ 3RA28 function modules
- ⑨ 3RA27 function modules for IO-Link, direct starting
- ⑩ Pneumatic delay block
- ⑪ Mechanical latching block
- ⑫ Link for paralleling, 3-pole, with terminal
- ⑬ Connection module (adapter and connector) for contactors with screw connection
- ⑭ Coil terminal module, on the top and bottom
- ⑮ Wiring modules, on the top and bottom (reversing duty)
- ⑯ Three-phase feeder terminal
- ⑰ Link for paralleling (star jumper), 3-pole, without connection terminal

For mountable overload relays see Chapter 5 "Protection Equipment --> Overload Relays".
 For fuseless load feeders see Chapter 6 "Load Feeders and Motor Starters" --> "3RA2 Load Feeders".