




Схемы подключения внешних цепей




6ES7 431-1KF00-0AB0




6ES7 431-1KF10-0AB0




6ES7 431-1KF20-0AB0




6ES7 431-0HH00-0AB0



6ES7 431-7KF00-0AB0



6ES7 431-7KF10-0AB0



6ES7 431-7QH00-0AB0