




Схемы подключения внешних цепей



6ES7 334-1CE01-0AA0



6ES7 334-0KE00-0AB0, 6AG1 334-0KE00-2AB0



6ES7 335-7HG01-0AB0